



2" OVERFILL VENT OR
.5 PSI PRESSURE RELIEF VALVE
OPTIONAL

4" FILL CAP

1.5" BALL VALVE

[INSTEAD OF VENT, ADD PIPE ELBOW AND RUN PIPE FROM CRAWL SPACE THROUGH FOUNDATION TO OUTSIDE TO REDIRECT OVERFLOW AWAY FROM HOUSE IN THE EVENT OF PUMP MALFUNCTION.]